








AVK BALL CHECK VALVE

SERIES 53

Mounting instruction / Montagevejledning
Einbauanleitung / Instruction de montage



Mounting distance downstream pumps and elbows min. 5 x DN.

*** Required opening pressure - AVK ball check valve.
For vertically installed ball check valve in an empty pipe system.
With standard ball.**

Dimension mm	PN bar	Dimension mm	PN bar
DN 32	0,007	DN 200	0,03
DN 40	0,016	DN 250	0,035
DN 50	0,012	DN 300	0,042
DN 65	0,019	DN 350	0,05
DN 80	0,012	DN 400	0,057
DN 100	0,016	DN 500	0,363
DN 125	0,032	DN 600	0,424
DN 150	0,022		